

Cutter Calibration

i-Tech i960 and MMC


It is recommended to calibrate the plotter to a dimension that is an average size cut you normally perform.

CALIBRATION INSTRUCTIONS:

- 1) Power on the machine, load material, and ready the position of the cutting head along with the force and speed.
- 2) Open the (Allen, i-Tech, or MMC) Remote Panel downloaded on your desktop.
May also be located in: Click Start > All Programs > Allen Datagraph


NOTE: If you do not have the remote panel, send a request to our technical support department with your serial number at <http://allendatagraph.com/tech-support/> and we will provide a direct link to download/install.

- 3) Click Setup > Com Port > (choose the com port the plotter is operating on)
- 4) Click Diagnostics > Calibration Square Plot
- 5) Enter the size of the X axis (media movement) cut you wish to calibrate to
- 6) Enter the size of the Y axis (carriage movement) cut you wish to calibrate to
- 7) The machine will now cut the calibration square
- 8) Measure the cut and record these values for X and Y measurements



If adjustment is necessary, continue:

- 9) Click Diagnostics > Calibrate 07
- 10) X Drawn = desired distance to cut in the X axis (media travel)
X Measured = actual measurement of the calibration square in the X axis
Y Drawn = desired distance to cut in the Y axis (carriage travel)
Y Measured = actual measurement of the calibration square in the Y axis
- 11) Click OK
- 12) Verify the percentage of changes are less than 4% and click OK
- 13) The cutter will reboot
- 14) Ready the plotter for another calibration square cut
- 15) Repeat steps 4 through 8 until calibration is achieved.



Contact ADSI Technical Support if you have any questions or concerns @ <http://allendatagraph.com/tech-support/>

