



Centering Guide Adjustment

Centra HS Printer

This document explains how to adjust the position of the tracking guides on the Centra HS Print Base. This procedure can be repeated for all (4) four guides.

- 1) Remove (4) four 2.5mm screws to separate the white guide

- Take note of the orientation of the plate and guide



- 2) Push the plate away from the center of the shaft to remove from blocks

- May require some force to slide off



- 3) Remove the 3mm screw to remove the (2) two blocks

- Mark the top so it can be reinstalled the same way



- 4) Rotate the collar inside the shaft to close/open gap between the guides.



- 5) Reverse steps to reinstall guides.

Contact ADSI Technical Support @ <http://allendatagraph.com/tech-support/>



56 Kendall Pond Road
Derry, NH 03038
603-216-6344
www.allendatagraph.com



All products made in The United States.
All specifications are subject to change.